Safety instructions

“HS 18” cordless hedge trimmer · model MG-HS18 · demo document

Read completely before first use and keep for future reference.

Work area

- Only work in daylight or good artificial light.
- Keep children, bystanders and pets away.
- Check the hedge for wires, fences and hidden objects before cutting.

Personal protective equipment

- Wear safety glasses, work gloves and sturdy shoes.
- Hearing protection is recommended.

Battery and charger

- Only use the original 18 V battery and a suitable charger (15–36 W).
- Do not store the battery above 45 °C and do not short-circuit it.
- Remove the battery before maintenance and transport.

While working

- Always hold the device with both hands on the intended handles.
- Do not touch the cutter bar while it is moving.
- Fit the blade guard for transport.

Musterfeld Gartentechnik GmbH · Musterstraße 12 · 12345 Musterstadt · Germany · service@example.com